

Care instructions for synthetic leather



General care instructions

As with all materials in daily use, furniture upholstery fabric requires care.

In order to prevent premature wear and staining, furniture that is covered with PU synthetic leather should be wiped regularly with a slightly moist cotton cloth. Any remaining damp patches should then be dried using a dry cotton cloth.

To avoid electrostatic charges, the relative humidity should be between 40 – 60%. If the room climate is too dry, the furniture can occasionally be wiped with a damp, but not too wet, cotton cloth.

Do not place the upholstery furniture too close to sources of heat such as radiators, ovens, fireplaces etc. A minimum clearance of 70 cm is recommended. Furthermore, upholstery furniture should be placed no closer than five or six centimetres to a wall. Protect furniture that is covered with PU synthetic leather from excessive sunlight and UV radiation in order to prevent uneven and premature fading.

Generally speaking, light colours are more sensitive and care-dependent than dark colours.

Cleaning and care

A specialist should be hired for cleaning and removing stains from upholstery. If you wish to perform this work yourself, you should only use the tested cleaning and care products of the LCK company.



Sedicur Care set



Sedicur Cleaning set